



INSTALLATION GUIDE

ALUMINIUM FRAMED ROOFLIGHT

Please see below guide to installing an **Aluminium Framed Rooflight**. Please note this is only a guide and we recommend you acquire the services of a professional builder/joiner to carry out the necessary works.

Step 1

Un-package the **Aluminium Framed Rooflight** by removing the protective corners.

Step 2

Check the up-stand is between 3 - 5 degrees and is clean ready for the sealant to be applied.

Step 3

Apply a bead of sealant around the top edge of the up-stand and runs all the way around. Make sure the bead of sealing is 10-12mm high.

STEP 4

Lower the **Aluminium Framed Rooflight** over the up-stand into position and press down firmly. Make sure there is a good adhesion all the way around.

Step 5

Once you are happy with its position bend the internal straps down and fasten into position with screws.

PLEASE NOTE:

The sealant used for sealing the **ALUMINIUM FRAMED ROOFLIGHT** to the upstand needs to be compatible with the roofing substrate

CONTACT

Tel: 020 3488 8089

Email: info@skyrooflights.com

Web: www.skyrooflights.com