



INSTALLATION GUIDE

FRAMELESS PYRAMID

Please see below guide to installing a frameless lantern/pyramid roof flight. Please note this is only a guide and we recommend you acquire the services of a professional builder/joiner to carry out the necessary works.

Required Tools:

- Silicone Gun
- Stanley Knife
- Silicone sealant (recommended Dow Corning 791 or similar)
- Compatible Sealant
- Cordless screwdriver
- Screws
- Level
- Packers

Step 1

Make sure you clean and dry the upstand which will ensure the sealant can adhere correctly for the weather sealing.

Step 2

Ensure that the upstand is level and square, use glazing packers if required to make sure the correct level is achieved to all sides.

Step 3

Apply a 10mm high bead of sealant to the top edge of the upstand (to all four sides).

STEP 4

Lower the Lantern/Pyramid into the correct position – press down firmly on all edges to ensure a tight seal is achieved.

Step 5

Screw the Lantern/Pyramid down through the holes provided. Make sure the screws are not over tightened. This process is then to be repeated to the internal perimeter of the Lantern/Pyramid ensuring all are screwed correctly.

CONTACT

Tel: 020 3488 8089

Email: info@skyrooflights.com

Web: www.skyrooflights.com